

Update Firmware on Meeting Pad via USB – 65/70 Inch F Series Only

Revision date: 22/12/2017



Instructions

 Please read entire instruction sheet before you start.

Tools

- 1 Blank USB Memory stick (minimum 1 GB capacity and FAT32 formatted)

Step 1

Download the firmware from the following link:

[65 Inch Firmware](#)

[70 Inch Firmware](#)

Step 2

Extract the .bin file from the .zip and copy it into the blank USB stick.

Step 3

Remove all peripherals from the screen except for the power cable.


Step 4

Keep the rocker switch on the back of the screen in the off position (O), and plug the USB stick into one of the USB ports on the back of the screen as illustrated below.



Step 5

Hold the power button on the front of the screen and turn the screen on via the on/off rocker switch on the rear of the unit while still holding the power button on the front of the screen.



Step 6

When the blue update screen appears, release the power button.

Step 7

The update process will take approximately 5 minutes; do not turn the screen off during this time.

Step 8

Once this has reached 100%, the screen will turn itself off.

Step 9

Remove the USB stick from the screen and turn the screen on using the power button on the front.

Step 10

The first booting time will be significantly longer than normal; please be patient and do not power off during this time.